



shimadzu



LC-10AD, 10ADVP, 600, 9A,
2010, 20-AT, 20-AD, 20-AB

optimax check valves

Optimize P/N	Optimize Description	shimadzu P/N
34-46-00885	OPTI-MAX Inlet Cartridge Check Valve LC-10AD, LC-600/LC-9A	228-33492-91 228-18522-91
34-46-02644	OPTI-MAX Inlet Cartridge Check Valve LC-10ADVP, LC-20AD, LC-20AB, LC-2010, LC-20AT	228-45704-91 228-39093-92
34-46-00893	OPTI-MAX Outlet Cartridge Check Valve LC-10ADVP, LC-20AD, LC-20AB, LC-2010, LC-20AT	228-34976-91 228-18522-92 228-45705-91 228-39093-92 228-32531-92 228-37147-93
10-46-02004	OPTI-MAX Replacement Cartridges, 1/16" ball, 2/pk	n/a

seals

Optimize P/N	Optimize Description	shimadzu P/N
34-36-00855	OPTI-SEAL UHMW-PE Plunger Seal LC-10AD, LC-600/LC-9A,	228-35146-00
34-36-00856	OPTI-SEAL UHMW-PE Plunger Seal LC-10AD, LC-600/LC-9A 10/Pk	n/a
34-36-00857	UHMW-PE/Elastomer Energized Plunger Seal LC-10AD, LC-600/LC-9A	28-35146-00
34-36-00858	UHMW-PE/Elastomer Energized Plunger Seal LC-10AD, LC-600/LC-9A 10/Pk	n/a

pistons

Optimize P/N	Optimize Description	shimadzu P/N
34-34-00853	Sapphire Plunger LC-10AD, LC-600/LC-9A	228-18523-91
34-34-02645	Sapphire Plunger Assembly, LC-10ADVP	228-35601-91

lamps

Optimize P/N	Optimize Description	shimadzu P/N
34-32-03102	DX2 DoubleLife™ D2 Lamp for LC 2010	228-37401-00



shimadzu



LC-10AT, 10ATVP, 10AS, 6A

seals

Optimize P/N	Optimize Description	shimadzu P/N
34-36-00863	ITB PTFE Piston Seal	228-11999-00
34-36-00865	OPTI-SEAL UHMW-PE Piston Seal	228-21975-00

pistons

Optimize P/N	Optimize Description	shimadzu P/N
34-34-01997	Sapphire Piston Assembly, LC-10AT	228-32654-91
34-34-02650	Sapphire Piston for LC-10ATVP	228-35009-92
34-34-01345	Sapphire Piston for LC-10AS	228-17019-93
34-34-00854	Sapphire Piston for LC-6A	228-12904-93

lamps

Optimize P/N	Optimize Description	shimadzu P/N
34-32-02837	DX2 DoubleLife™ D2 Lamp for 10AS, 10AVP	228-37401-00

optimax check valves

Optimize P/N	Optimize Description	shimadzu P/N
34-46-01983	OPTI-MAX Inlet Cartridge Check Valve & Housing for LC-10AT, LC-10ATVP	228-32166-91
34-46-00893	OPTI-MAX Outlet Cartridge Check Valve & Housing for LC-10AT, LC-10ATVP	228-39093-92 228-32531-92
34-56-00902	OPTI-MAX Inlet Cartridge Check Valve & Housing for LC-10AS, LC-6A	228-12353-91
34-56-00907	OPTI-MAX Outlet Cartridge Check Valve & Housing for LC-10AS, LC-6A	228-09054-93
10-56-02004	OPTI-MAX Replacement Cartridges, 1/8" Ball, 2/pk	n/a

